



## APPLICATION INSTRUCTIONS

Thank you for your recent purchase of ConcreteRevive™. These comprehensive instructions should answer any questions you might have and ensure that your experience with this state-of-the-art coating is a successful one. When you read through these instructions first and follow them, you will enjoy a beautiful new concrete surface that will last for years to come. Thanks again for your confidence in our products. Should you have additional questions, please visit our website at [www.gulfsynthetics.com](http://www.gulfsynthetics.com).

**COVERAGE:** Each kit of ConcreteRevive™ is packaged in a five-gallon container for easy mixing. The kit contains two parts: (1) liquid resin and (2) dry chemistry. **YOU ADD** one gallon of exterior acrylic latex paint (any color of gloss). With two coats applied, the coverage will be approximately 200 square feet per kit depending on surface porosity and texture.

**IMPORTANT NOTE:** This product is designed to produce results using the exact proportions provided in the kit and in compliance with the instructions written below. Variance from these proportions, either more or less, of the three ingredients mentioned above will not be warranted by the manufacturer.

**SURFACE PREPARATION:** For best results, we recommend the surface to be **CLEAN, DRY, DULL, PH NEUTRAL, and of MODERATE TEMPERATURE.**

**CLEAN:** Surfaces must be thoroughly clean, free of dirt, sealer or waxes, peeling paint, mildew, tar, glaze, efflorescence, laitance, grease or oily substances. Loose mortar or cement must be removed. Clean the surface by power washing, and allow substrate to **dry completely** for a minimum of 48 hours.

**DRY:** The surface needs to be **thoroughly dry**. Never apply over wet concrete. For exterior projects, do not apply if precipitation is predicted in the next 24 hours. Test concrete for possible moisture problems by taping an 18" X 18" plastic film to the concrete and observing it for 24 hours. If condensation is observed, moisture is present and the source must be identified and contained before proceeding.

**DULL:** Glossy, painted, or sealed surfaces must be dulled by grinding or acid etching. If a clear concrete sealer is on the surface that is to be coated, the surface should be acid etched using a 10 percent muriatic acid solution or grinded to produce a profile for the ConcreteRevive™ coating to bond to. Then the surface is to be cleaned thoroughly by power washing. **Note:** When using muriatic acid, follow manufacturer's specifications. For aged asphalt driveways (3+ years), follow same preparation instructions as concrete surfaces.

**PH NEUTRAL:** New concrete has a very high PH. Allow new concrete to cure 30-60 days at 75°F before coating. Concrete should have a PH of 7-9 before applying this product.

**MODERATE TEMPERATURE:** For best results apply between 40-85°F. Do not apply if ambient temperature or the surface temperature is <40° or >85°F. If temperature is less than 40°F this product will cure too slowly or maybe not at all. If temperatures exceed 85°F, this coating will set too quickly. Additionally, do not apply coating if temperature is predicted to drop below 40°F within the next 24 hours.

**PREPPING HOLES AND CRACKS:** ConcreteRevive™ is quite thick and will easily fill most small cracks. If existing cracks are excessive (over 3/8" deep and wide), use PermaFill™, Do not smear

caulk/patching material on adjacent concrete surface. PermaFill may take 2-4 hours to cure and must be properly dried or cured before applying ConcreteRevive™.

**PermaBond Primer is Required** over previously painted or stained concrete.

#### **APPLICATION PROCEDURE FOR ONE KIT:**

1. **Remove both wet and dry chemistry** from container.
2. **Empty liquid resin** into container.
3. **Add one gallon of exterior latex gloss paint** (any color) to liquid resin. **Mix briskly for two minutes.**
4. **Slowly add dry chemistry while mixing briskly with drill and paint mixer (recommended Electric Drill) for 5 minutes. (DO NOT USE A CEMENT MIXER).** Stir mixture to loosen up any dry portion from the bottom of container. Dry chemistry components should break down completely and mix should be smooth and viscous. Let the coating sit for **5 minutes**, then mix briskly for another **5 minutes**. The coating is now activated and should be used immediately for best results.
5. **Do not alter the chemistry of the product in any way by adding or subtracting material or by adding other ingredients (DO NOT ADD WATER or EXTRA PAINT).**
6. If you are working on a large area with more than one kit, mix each kit separately and then blend or 'box' together for color consistency.
7. Use typical 'cut-in' techniques around adjacent structures, etc. During application stir product every hour. Cut-in with two coats. Allow to dry completely between coats. Between coats, reseal lid and keep out of direct heat.
8. **Allow ConcreteRevive™ to dry** to the touch, usually about 1 hour under recommended temperature and humidity. However, if it is very cool or very humid it could take longer and conversely; if it is warmer and dryer, it could take less time to dry.
9. **For best coverage, use a 3/8" nap paint roller and apply the first coat** in a north-south direction. Allow to dry completely before applying the second coat.
10. **Apply second coat** in an east-west direction. The second coat is key to attaining the proper texture. Use a 3/4" nap (or larger) roller for second coat. Nap size determines texture and affects sq ft coverage of product. If a more aggressive non-slip texture is desired, use a 1" nap roller for second coat. Apply second coat immediately following the application and drying of the first coat. Be consistent in your technique. Allow to dry.
11. Additional coats may be applied to build the final mil thickness, if desired. Mixed coating has a 21-day shelf life but should be used immediately for best results.
12. After ConcreteRevive™ is applied and thoroughly dried (approx. 24 hours) we recommend a non-yellowing clear acrylic waterborne sealer for garage floors and driveways. The sealer will add a layer of protection from HOT tire pick-up and make clean up easier in areas where food, dirt and grease collect easily. Follow sealer manufacturer's recommendations for best results.

**CLEAN UP:** Clean tools with water. Never dispose of excess coating while still in liquid state. Dispose of with accordance to all local, state, and federal guidelines. Buckets should be cleaned and re-used or recycled.

**SUGGESTED MAINTENANCE:** In areas with high traffic, it is suggested that the clear acrylic waterborne sealers be watched, and based upon the eventual wear of the topical sealer, a new coat be applied as needed. Follow sealer manufacturer's directions for best use.

In exterior applications where no sealer is desired, it is recommended to keep surface clean of leaves, dirt and other debris. Wet leaves and other debris can cause staining.

**CLEANING:** With a mild detergent soap and water solution, using a soft bristle brush or rag mop, clean the surface gently and rinse thoroughly (DO NOT use a detergent with a de-greaser).



## 1/4 APPLICATION INSTRUCTIONS

Thank you for your recent purchase of ConcreteRevive™. These comprehensive instructions should answer any questions you might have and ensure that your experience with this state-of-the-art coating is a successful one. When you read through these instructions first and follow them, you will enjoy a beautiful new concrete surface that will last for years to come. Thanks again for your confidence in our products. Should you have additional questions, please visit our website at [www.gulfsynthetics.com](http://www.gulfsynthetics.com).

**COVERAGE:** Each 1/4 kit of ConcreteRevive™ is packaged in a two-gallon container for easy mixing. The kit contains two parts: (1) liquid resin and (2) dry chemistry. YOU ADD one quart of exterior acrylic latex paint (any color of gloss). With two coats applied, the coverage will be approximately 50 square feet per kit depending on surface porosity and texture.

**IMPORTANT NOTE:** This product is designed to produce results using the exact proportions provided in the kit and in compliance with the instructions written below. Variance from these proportions, either more or less, of the three ingredients mentioned above will not be warranted by the manufacturer.

**SURFACE PREPARATION:** For best results, we recommend the surface to be **CLEAN, DRY, DULL, PH NEUTRAL, and of MODERATE TEMPERATURE.**

**CLEAN:** Surfaces must be thoroughly clean, free of dirt, sealer or waxes, peeling paint, mildew, tar, glaze, efflorescence, laitance, grease or oily substances. Loose mortar or cement must be removed. Clean the surface by power washing, and allow substrate to **dry completely** for a minimum of 48 hours.

**DRY:** The surface needs to be **thoroughly dry**. Never apply over wet concrete. For exterior projects, do not apply if precipitation is predicted in the next 24 hours. Test concrete for possible moisture problems by taping an 18" X 18" plastic film to the concrete and observing it for 24 hours. If condensation is observed, moisture is present and the source must be identified and contained before proceeding.

**DULL:** Glossy, painted, or sealed surfaces must be dulled by grinding or acid etching. If a clear concrete sealer is on the surface that is to be coated, the surface should be acid etched using a 10 percent muriatic acid solution or grinded to produce a profile for the ConcreteRevive™ coating to bond to. Then the surface is to be cleaned thoroughly by power washing. **Note:** When using muriatic acid, follow manufacturer's specifications. For aged asphalt driveways (3+ years), follow same preparation instructions as concrete surfaces.

**PH NEUTRAL:** New concrete has a very high PH. Allow new concrete to cure 30-60 days at 75°F before coating. Concrete should have a PH of 7-9 before applying this product.

**MODERATE TEMPERATURE:** For best results apply between 40-85°F. Do not apply if ambient temperature or the surface temperature is <40° or >85°F. If temperature is less than 40°F this product will cure too slowly or maybe not at all. If temperatures exceed 85°F, this coating will set too quickly. Additionally, do not apply coating if temperature is predicted to drop below 40°F within the next 24 hours.

**PREPPING HOLES AND CRACKS:** ConcreteRevive™ is quite thick and will easily fill most small cracks. If existing cracks are excessive (over 3/8" deep and wide), use PermaFill™. Do not smear caulk/patching material on adjacent concrete surface. PermaFill may take 2-4 hours to cure and must be properly dried or cured before applying ConcreteRevive™.

**PermaBond Primer is Required** over previously painted or stained concrete.

## APPLICATION PROCEDURE FOR ONE KIT:

1. **Remove both wet and dry chemistry** from container.
2. **Empty liquid resin** into container.
3. **Add one quart of exterior acrylic latex paint** (any color) to liquid resin. **Mix briskly for two minutes.**
4. **Slowly add dry chemistry** while **mixing briskly with drill and paint mixer (recommended Electric Drill) for 5 minutes. (DO NOT USE A CEMENT MIXER).** Stir mixture to loosen up any dry portion from the bottom of container. Dry chemistry components should break down completely and mix should be smooth and viscous. Let the coating sit for **5 minutes**, then mix briskly for another **5 minutes**. The coating is now activated and should be used within 24 hours.
5. **Do not alter the chemistry of the product in any way by adding or subtracting material or by adding other ingredients (DO NOT ADD WATER or EXTRA PAINT).**
6. If you are working on a large area with more than one kit, mix each kit separately and then blend or 'box' together for color consistency.
7. Use typical 'cut-in' techniques around adjacent structures, etc. During application stir product every hour. Cut-in with two coats. Allow to dry completely between coats. Between coats, reseal lid and keep out of direct heat.
8. **Allow ConcreteRevive™ to dry** to the touch, usually about 1 hour under recommended temperature and humidity. However, if it is very cool or very humid it could take longer and conversely; if it is warmer and dryer, it could take less time to dry.
9. **For best coverage, use a 3/8" nap paint roller and apply the first coat** in a north-south direction. Allow to dry completely before applying the second coat.
10. **Apply second coat** in an east-west direction. The second coat is key to attaining the proper texture. Use a 3/4" nap (or larger) roller for second coat. Nap size determines texture and affects sq ft coverage of product. If a more aggressive non-slip texture is desired, use a 1" nap roller for second coat. **Be consistent in your technique.** Allow to dry.
11. Additional coats may be applied to build the final mil thickness, if desired. Mixed coating must be used within 24 hours.
12. After ConcreteRevive™ is applied and thoroughly dried (approx. 24 hours) we recommend a non-yellowing clear acrylic waterborne sealer for garage floors and driveways. The sealer will add a layer of protection from HOT tire pick-up and make clean up easier in areas where food, dirt and grease collect easily. Follow sealer manufacturer's recommendations for best results.

**CLEAN UP:** Clean tools with water. Never dispose of excess coating while still in liquid state. Dispose of with accordance to all local, state, and federal guidelines. Buckets should be cleaned and re-used or recycled.

**SUGGESTED MAINTENANCE:** In areas with high traffic, it is suggested that the topical sealer be watched, and based upon the eventual wear of the topical sealer, a new coat be applied as needed. Follow sealer manufacturer's directions for best use.

In exterior applications where no sealer is desired, it is recommended to keep surface clean of leaves, dirt and other debris. Wet leaves and other debris can cause staining.

**CLEANING:** With a mild detergent soap and water solution, using a soft bristle brush or rag mop, clean the surface gently and rinse thoroughly (DO NOT use a detergent with a de-greaser).

(Revised (1/01/13))